

Advanced Microsystems for Automotive Applications 2012
Berlin / Germany, 30 May 2012

Battery Management Network for Fully Electrical Vehicles Featuring Smart Systems at Cell and Pack Level


Alexander Otto, Sven Rzepka, Thomas Mager, Bernd Michel, Claudio
Lanciotti, T. Günther, Olfa Kanoun

Micro Materials Center, Fraunhofer ENAS
Technologie-Campus 3, 09126 Chemnitz
alexander.otto@enas.fraunhofer.de; +49-371-45001-425







Micro Materials Center
Prof. B. Michel, Dr. S. Rzepka

Outline




I. Introduction | Challenges

Driving Range $\uparrow \Rightarrow$ Energy Density [kWh/kg] \uparrow

- Li-Ion Technology 
- Specific Cell Chemistry 
 - Cathode (LiCoO_2 , LiMn_2O_4 , LiFePO_4 , ..., Li, ...)
 - Anode (Graphite, Li Alloy, Air, ...)
 - Electrolyte – liquid (LiPF_6), solid (PVDF)
 - Separator (porous foils - org., ceramics, ...)
 - Design (round, pouch; parallel, in series, ...)
- Energy/Power Density \uparrow - Cost 
- Energy/Power Density \uparrow - Safety 



I. Introduction | Hierarchical structure of battery systems



- Basic cell chemistry
- Basic voltage level


- Stack of (e.g. 20) mono-cells connected in parallel

- Many cells in series

- Several modules, or
- Many cells
- Voltage: 400 V


- Several battery packs in parallel
- Energy: >15 kWh

II. Battery Management | State-of-the-art




Superior tasks of the BMS:

- To assure the safety of battery and user
- To prolong the lifetime
- To keep battery in desired operating status and every time ready for use



Source: http://www.notebook-check.com/Newsbeitrag_54+M56d337ec94d.0.html

II. Battery Management | Trend to distributed intelligence



II. Battery Management | Trend to distributed intelligence


Goal: Integration of Smart Systems into every single electrochemical cell:

- Sensors (V, I, T, P/Def., EIS,...)
- Signal conditioning and processing
- Data storage and management
- Communication
- Balancing, actuators

Advantages to be achieved:

- Usage of Li-Ion-Battery systems with higher Energy density
- Lifetime: Battery \geq Car
- **Consequences:**


- Cost-of-ownership $\downarrow \Rightarrow$ Customer acceptance E-Car \uparrow
- Electronic partition \uparrow / Importance Reliability \uparrow



III. Smart-LIC | New BMS architecture

Smart-LIC Cell System:

- [1] (Emergency) Switch; [2] Fuse
- [3] Current Measurement (Shunt, Hall, MR Effect)
- [4] Cell Balancing: Passiv (Switch & Bypass in the Cell) & Active (Capacitor / Coil next to Cell)
- [5] Voltage measurement
- [6] Electro-chemical Impedance Spectroscopy → SoF(SoC, SoH)
- [7] Internal Power Supply (DC/DC converter)
- [8] Microcontroller
- [9] Transceiver to/from central BMS
- [10] Temperature Sensor
- [11] Pressure Sensor





III. Smart-LIC | Intermediate step: Smart 'Macro-cell'

Smart macro-cell as 1. Generation:

- Sealed metal case with rupture disk, containing 4 cells connected in series
- Technical parameter:
 - 14,4V, 20Ah, 288Wh (based on NCM cells)
 - Maximum current: 100A (5C)
 - H=260, W=148, L=38 [mm]

⇒ Goal:

1. Showing of feasibility of envisaged architecture for simplified interim solution
2. Additional demonstrator for benchmarking purposes



III. Smart-LIC | New EIS based battery models


Electrochemical Impedance Spectroscopy (EIS)

- Simultaneously extraction of cell voltage and current parameters at (macro-) cell level
- 2 different approaches under investigation:
 - U / I measurement on battery charge/discharge
 - Modulation by balance switches


⇒ Accurate information regarding actual cell status as well as of future cell behavior

⇒ Batteries always run at optimum conditions → Longer cyclic life

EIS = f (SoH):



EIS = f (SoC)



III. Smart-LIC | Investigation of deformation behavior


Deformation due to **Intercalation**

- Novel method for battery state determination (SoC, SoH -> ageing dependent outgassing)



Deformation due to **Safety Issues**

- Redundancy to temperature measurement, but faster in case of safety issues



microDAC© method




CT Examination



CT images of a bloated Li-Ion cell



III. Smart-LIC | Communication



Wireless Communication between Cells & central BMS

= no cabling and connectors:


- Reduction of Cost, Volume & Mass
- Improvement of Electro-Chemical and Mechanical Reliability
- Misconnection is impossible
- Optimum & simplified Maintenance

Challenges


- EMC: 200 nW ↔ 200 kW (9 OoM)
- Metal Housing with Numerous Complex Paths of Interference

⇒ Optimization of Communication


Cavity (All Walls metallic)




Waveguide (Wall 1 and 2 open)




III. Smart-LIC | System integration




SoA: Complex housing with various materials and complex assembly



Novel Approach:
Moulded ECU with leadframe contacts



III. Smart-LIC | Reliability





III. Smart-LIC | Safety improvements

...due to more advanced cell and battery state monitoring:


- Temperature measurement at cell level with redundant pressure sensing + EI-Spectroscopy

...due to switching-off of individual (macro-) cells in case of malfunction or accident:

- Preventing (the spread) of a thermal runaway
- Increased safety for the rescue team by shutting down of high battery voltage



S1 = S2 = STV300NH02L



Ribbons

$R_{DS(on)} = 0,8m\Omega$


III. Smart-LIC | Safety Concept: Functional BMS when needed most

Joining technology for very high temperature applications



- Cell operation: -30°C ... +70°C
- Malfunction Temp.: 250°C and higher
- Technology: Isothermal solidification
- Example: Cu₃Sn, Cu₆Sn₅ (>400°C)
- HotPowCon: Material systems, tools, and processes for Cu/Sn-IMP joints

Challenges

- Stiffness and brittleness of IMP
- System compatibility and reliability
→ New pad and substrate design
- New tests for product qualification




20 wt.-% Cu
Scheider-Ramelow: Tutorial 'High Temperature Packaging'; SMT-Hybrid 2010



IV. Summary & Conclusion

Integration of Smart Systems into Battery Cells brings ...

- ❑ Higher efficiency due to **local control** at cell level
- ❑ Increased precision in determining SoC, SoH, and SoF due to implementation of a **new cell / battery model** based on electrochemical impedance spectroscopy (**EIS**)
- ❑ Lower system complexity by reduction of wiring due to **wireless communication** between cell & central BMS
- ❑ Increased overall reliability due to **removing major sources of failures** and detecting degradations at earliest stage
- ❑ Increased safety so that cells can perform at **maximum rating** without thermal risks due to redundant sensors and HT joints
- ❑ Reduced repair cost of the battery packs achieved by **continuous monitoring** of each cell - specific maintenance advises
- ❑ Reduced cost of ownership for the end user due increase in battery lifetime caused by the **smart battery management**



Contact:

Alexander Otto

alexander.otto@enas.fraunhofer.de

Micro Materials Center, Fraunhofer ENAS
Technologie-Campus 3, 09126 Chemnitz

